

Edge Intelligence

Assessment (Lab Task - 2)

M Rahul – 25MML0011

Task 1 :-

Analyzing an image dataset-Mnist , applying basic preprocessing operations, using either ANN and CNN. Saving the model using pickle module. Key takeaway: understanding the dataset and saving the model using pickle module.

```
[3]
✓ 0s
import tensorflow as tf
from tensorflow.keras.models import Sequential
from tensorflow.keras.layers import Conv2D, MaxPooling2D, Flatten, Dense
from tensorflow.keras.utils import to_categorical

[4]
✓ 0s
# 1. Load MNIST dataset
(x_train, y_train), (x_test, y_test) = tf.keras.datasets.mnist.load_data()

Downloading data from https://storage.googleapis.com/tensorflow/tf-keras-datasets/mnist.npz
11490434/11490434 ————— 0s 0us/step

[5]
✓ 0s
# 2. Preprocess data
x_train = x_train / 255.0
x_test = x_test / 255.0

x_train = x_train.reshape(-1, 28, 28, 1)
x_test = x_test.reshape(-1, 28, 28, 1)

y_train = to_categorical(y_train, 10)
y_test = to_categorical(y_test, 10)

[7]
✓ 0s
# 3. Build CNN model
model = Sequential([
    Conv2D(32, (3,3), activation='relu', input_shape=(28,28,1)),
    MaxPooling2D((2,2)),

    Conv2D(64, (3,3), activation='relu'),
    MaxPooling2D((2,2)),

    Flatten(),
    Dense(128, activation='relu'),
    Dense(10, activation='softmax')
])

/usr/local/lib/python3.12/dist-packages/keras/src/layers/convolutional/base_conv.py:113: UserWarning: Do not pass an `input_shape` in
super().__init__(activity_regularizer=activity_regularizer, **kwargs)
```

[8]
✓ Os

```
# 4. Compile model
model.compile(
    optimizer='adam',
    loss='categorical_crossentropy',
    metrics=['accuracy']
)
```

[11]
✓ Os

```
model.summary()
```

... Model: "sequential"

Layer (type)	Output Shape	Param #
conv2d (Conv2D)	(None, 26, 26, 32)	320
max_pooling2d (MaxPooling2D)	(None, 13, 13, 32)	0
conv2d_1 (Conv2D)	(None, 11, 11, 64)	18,496
max_pooling2d_1 (MaxPooling2D)	(None, 5, 5, 64)	0
flatten (Flatten)	(None, 1600)	0
dense (Dense)	(None, 128)	204,928
dense_1 (Dense)	(None, 10)	1,290

Total params: 675,104 (2.58 MB)
Trainable params: 225,034 (879.04 KB)
Non-trainable params: 0 (0.00 B)
Optimizer params: 450,070 (1.72 MB)

[9]
✓ 5m

```
# 5. Train model
model.fit(x_train, y_train, epochs=5, batch_size=64)
```

Epoch 1/5
938/938 ————— 47s 48ms/step - accuracy: 0.8919 - loss: 0.3606
Epoch 2/5
938/938 ————— 80s 47ms/step - accuracy: 0.9843 - loss: 0.0507
Epoch 3/5
938/938 ————— 82s 46ms/step - accuracy: 0.9895 - loss: 0.0331
Epoch 4/5
938/938 ————— 83s 48ms/step - accuracy: 0.9935 - loss: 0.0210
Epoch 5/5
938/938 ————— 44s 46ms/step - accuracy: 0.9951 - loss: 0.0151
<keras.src.callbacks.history.History at 0x7eb34e563e60>

[12]
✓ 3s

```
# 6. Evaluate model
loss, accuracy = model.evaluate(x_test, y_test)
print("Test Accuracy:", accuracy)
```

... 313/313 ————— 3s 10ms/step - accuracy: 0.9899 - loss: 0.0316
Test Accuracy: 0.9922000169754028

[13]

✓ 0s



```
import pickle

# Save model architecture (config)
model_config = model.to_json()

# Save model weights
model_weights = model.get_weights()

with open("cnn_model.pkl", "wb") as f:
    pickle.dump((model_config, model_weights), f)

print("Model saved using pickle")
```



... Model saved using pickle

[14]

✓ 0s

```
import pickle
from tensorflow.keras.models import model_from_json

with open("cnn_model.pkl", "rb") as f:
    model_config, model_weights = pickle.load(f)

# Rebuild model
loaded_model = model_from_json(model_config)
loaded_model.set_weights(model_weights)

# Compile again
loaded_model.compile(
    optimizer='adam',
    loss='categorical_crossentropy',
    metrics=['accuracy']
)

print("Model loaded successfully")
```



Model loaded successfully

Task 2 :-

1.Create account in edge impulse,

2.go to data acquisition .

3.Choose connect data option.

4.scan qr using phone.

5. Select Label data before clicking a photo.

6. Split the clicked photos into train and test data

The screenshot displays the Edge Impulse web interface for a project named 'rahulmarripudi / rahulmarripudi-project-1'. The interface is divided into several sections:

- Left Sidebar:** Contains navigation links for Dashboard, Devices, Data acquisition, Experiments, EON Tuner, Impulse design, Versioning, and GETTING STARTED (Documentation, Forums). An 'Upgrade Plan' button is also present.
- Top Navigation:** Includes tabs for Dataset, Data explorer, Data sources, Synthetic data, AI labeling (marked as NEW), and CSV Wizard. The current user is 'rahulmarripudi'.
- Dataset Overview:** Shows 'DATA COLLECTED 16 items' and a 'TRAIN / TEST SPLIT 69% / 31%'.
- Dataset Table:** A table with columns 'SAMPLE NAME', 'LABEL', and 'ADDED'. It lists 16 items, including 'Laptop charger', 'Mouse', 'Pen', 'I'd card', 'Laptop', and 'Book'. The 'Laptop' entry is highlighted.
- Collect data Panel:** Includes a 'Device' dropdown (currently showing 'No devices connected'), a 'Label' input field, a 'Sample length (ms.)' input field (set to 5000), a 'Sensor' dropdown, and a 'Frequency' dropdown. A 'Start sampling' button is located at the bottom right of this panel.
- RAW DATA Section:** A dark blue box with the text 'Click on a sample to load...'.